



FIGURE 25 - LANDING GEAR FAIRINGS

KEY	ITEM NO.	PART NUMBER	1	2	3	4	NOMENCLATURE	UNITS PER ASSY	USAGE
1	2850	145-33302-3SA#100					Door Assy - Main Landing Gear Fairing LH - - - - -	1	1890 & Subs
	2851	145-33302-4SA#100					Door Assy - Main Landing Gear Fairing RH - - - - -	1	1890 & Subs
2	2855	145-33302-8					Bracket Assy - - - - -	1	
		AN526-1032-R9					Screw - - - - -	2	
		AN365-1032					Nut - Self Locking - - - - -	2	
3	2856	145-33302-9					Bracket Assy - - - - -	2	
4	2857	145-33302-18					Clamp Ear - - - - -	1	
		AN3-6A					Bolt - Bracket Attaching - - - - -	1	
		AN365-1032					Nut - Bracket Attaching - - - - -	1	
		AN3-15A					Bolt - Aircraft 10-32 - - - - -	1	
		AN365-1032					Nut - Self Locking - - - - -	1	
5	2888	145-33309					Spacer - - - - -	1	
6	2889	145-33309-2					Spacer - - - - -	1	
7	2858	145-33302-10					Stop Assy - - - - -	2	
		AN503-8-8					Screw - Stop Angle Attaching - - - - -	2	
		AN935-8					Washer - Stop Angle Attaching - - - - -	2	
8	2859	145-33303-3					Link - Main Gear Fairing Operating - - - - -	1	
	2860	145-33303-5					Stud - - - - -	1	
9	9461	F34-14					Rod End - - - - -	2	
		AN316-4R					Nut - Aircraft Check - - - - -	2	
		AN380-2-3					Cotter - - - - -	1	
10	2861	145-33302-11					Angle - - - - -	1	
	2862	145-33302-12					Hinge Half - Main Gear Fairing RH - - - - -	1	
11	2863	145-33302-13					Hinge Half - Main Gear Fairing LH - - - - -	1	
12	2867	145-33302-17					Hinge Pin - Main Gear Fairing - - - - -	1	
13	9191-3	D-31-100					Wheel Cover - - - - -	2	
14	9191-4	B-85-95					Snap Ring - - - - -	1	
15	2868	145-33306-1SA#100					Door Assy - Nose Wheel Fairing LH - - - - -	1	1890 & Subs
	2869	145-33306-2SA#100					Door Assy - Nose Wheel Fairing RH - - - - -	1	1890 & Subs
16	2872	145-33306-13					Clip - - - - -	1	
17	2873	145-33306-14					Clip - - - - -	1	
		AN526-1024-14					Screw - Truss Head (Coarse & Fine Thread) - - - - -	2	
		AN365-1024					Nut - Self Locking - - - - -	2	
		AN960-10					Washer - Plain - - - - -	2	
	2878	145-33303-2					Link Assy - Nose Gear Fairing - - - - -	2	
18	2879	145-33303-4					Stud - - - - -	1	
19	9461	F34-14					Rod End - - - - -	2	
		AN316-4R					Nut - Aircraft Check - - - - -	2	
		AN380-2-3					Cotter - - - - -	2	
20	2823	145-34143-3					Collar Assy - Nose Gear - - - - -	1	
	8011	4B16CF6-8					Bearing - - - - -	2	
21	2880	145-33307					Spring Assy - Nose Wheel Fairing - - - - -	1	
22	2883	145-33308-7					Stop Assy - Nose Wheel Fairing - - - - -	1	
23	2884	145-33305					Bearing Block Assy - Nose Wheel Fairing - - - - -	2	
	2885	145-33305-3					Block - - - - -	1	
	9462	LS38					Bearing - Press Fit - - - - -	1	
24	2886	145-33304-3					Arm Assy - Nose Wheel Fairing Actuating - - - - -	1	
25	2887	145-33304-4					End Assy - Nose Wheel Fairing Actuating Arm - - - - -	2	
		AN316-6R					Check Nut - - - - -	2	
26	2875	145-33306-9					Hinge - Half - - - - -	2	
27	2876	145-33306-11					Hinge Pin - - - - -	2	