



FIGURE 2 - WING PANEL STRUCTURE

KEY	ITEM NO.	PART NUMBER	1	2	3	4	NOMENCLATURE	UNITS PER ASSY	USAGE
1	1100	143-14003-1	Spar	Assy	-Station 0 to 50	Front LH	- - - - -	1	
	1101	143-14003-2	Spar	Assy	-Station 0 to 50	Front RH	- - - - -	1	
2	1102	143-14004-1	Spar	Assy	-Station 0 to 50	Center LH	- - - - -	1	
	1103	143-14004-2	Spar	Assy	-Station 0 to 50	Center RH	- - - - -	1	
3	1104	143-14006-11	Beam	Assy	-Station 0 to 50	Front LH	- - - - -	1	
	1105	143-14006-12	Beam	Assy	-Station 0 to 50	Front RH	- - - - -	1	
4	1108	143-33152	Fitting	Assy	-Main Ldg.	Gear Trunnion Bearing	- - - - -	2	
5		AN5-6A	Bolt-Aircraft		5/16-24	- - - - -	- - - - -	7	
6		AN960-516	Washer-Plain	- - - - -	- - - - -	- - - - -	- - - - -	11	
7		AN365-524	Nut-Self Locking	- - - - -	- - - - -	- - - - -	- - - - -	7	
8	1106	143-14006-21	Beam	Assy	-Landing Gear	Support Aft LH	- - - - -	1	
	1107	143-14006-22	Beam	Assy	-Landing Gear	Support Aft RH	- - - - -	1	
9	1108	143-33152	Fitting	Assy	-Main Ldg.	Gear Trunnion Bearing	- - - - -	1	
10		AN5-5A	Bolt-Aircraft		5/16-24	- - - - -	- - - - -	4	
11		AN960-516	Washer-Plain	- - - - -	- - - - -	- - - - -	- - - - -	4	
12		AN365-524	Nut-Self Locking	- - - - -	- - - - -	- - - - -	- - - - -	1	
13	1110	143-14060-3	Former	-Station 6	Lower LH	- -	- - - - -	1	
	1111	143-14060-4	Former	-Station 6	Lower RH	- -	- - - - -	1	
14	1112	143-14065-3	Former	-Station 6.594	Upper LH	- -	- - - - -	1	
	1113	143-14065-4	Former	-Station 6.594	Upper RH	- -	- - - - -	1	
15	1118	145-14112-3	Former	-Station 12.250	Lower LH	- -	- - - - -	1	
	1119	145-14112-4	Former	-Station 12.250	Lower RH	- -	- - - - -	1	
16	1122	143-14015-3	Former	-Station 15.406	Upper LH	- -	- - - - -	1	
	1123	143-14015-4	Former	-Station 15.406	Upper RH	- -	- - - - -	1	
17	1128	145-14124-3	Former	-Station 24.5	Upper LH	- -	- - - - -	1	
	1129	145-14124-4	Former	-Station 24.5	Upper RH	- -	- - - - -	1	
18	1132	145-14125-3	Former	-Station 24.5	Lower LH	- -	- - - - -	1	
	1133	145-14125-4	Former	-Station 24.5	Lower RH	- -	- - - - -	1	
19	1138-10	145-14137-3	Former	-Station 37.25	Upper LH	- -	- - - - -	1	
	1139-10	145-14137-4	Former	-Station 37.25	Upper RH	- -	- - - - -	1	
20	1140-10	145-14138-3	Former	-Station 37.25	Lower LH	- -	- - - - -	1	
	1141-10	145-14138-4	Former	-Station 37.25	Lower RH	- -	- - - - -	1	
21	1154	143-14052-3	Former	-Tank End	Support LH	- -	- - - - -	1	
	1155	143-14052-4	Former	-Tank End	Support RH	- -	- - - - -	1	