



FIGURE 7 - FORWARD FUSELAGE (CONT.)

| KEY | ITEM NO. | PART NUMBER | 1 | 2 | 3 | 4 | NOMENCLATURE | UNITS PER ASSY | USAGE |
|-----|----------|----------------|--------------|---|----------------------------------------------|---|--------------|-------------------|-------------|
| 65 | 1513 | 143-31001-71 | Angle | - | Nose Gear Box to Firewall LH | - | - | 1 | |
| | 1514 | 143-31001-72 | Angle | - | Nose Gear Box to Firewall RH | - | - | 1 | |
| 66 | 1480 | 143-51907 | Beam Assy | - | Instrument Panel to Firewall RH | - | - | 1 | 2 - 1270 |
| | 1480-10 | 143-51907-100 | Beam Assy | - | Instrument Panel to Firewall RH | - | - | 1 | 1271 & Subs |
| 67 | 1491 | 143-51007-4 | Beam | - | Instrument Panel to Firewall RH | - | - | 1 | |
| 68 | 1492-10 | 143-51007 SA 1 | Bracket Assy | - | Instrument Panel to Firewall Beam | - | - | 1 | |
| 69 | 1494 | 143-51007-12 | Fairlead | - | Instrument Panel to Firewall Beam | - | - | 1 | |
| 70 | 1495 | 143-51007-14 | Clip | - | Instrument Panel to Firewall Beam | - | - | 1 | |
| 71 | 1466 | 143-31001-103 | Baffle | - | Engine Cooling Air Outlet LH | - | - | 1 | 2 - 1789 |
| | 1466-10 | 143-31001-212 | Baffle | - | Engine Cooling Air Outlet LH | - | - | 1 | 1790 & Subs |
| | 1467 | 143-31001-104 | Baffle | - | Engine Cooling Air Outlet RH | - | - | 1 | 2 - 1564 |
| | 1467-10 | 143-31001-202 | Baffle | - | Engine Cooling Air Outlet RH (Fastener Type) | - | - | 1 | 1565 - 1789 |
| | 1467-20 | 143-31001-210 | Baffle | - | Engine Cooling Air Outlet RH (Fastener Type) | - | - | 1 | 1790 & Subs |
| 72 | 9002 | 1803-M-1 | Speednut | - | - | - | - | 10 | |
| 73 | | AN530-8R6 | Screw | - | Sheet Metal Round Head | - | - | 10 | |
| 74 | 1465-10 | 145-31101-10 | Step Assy | - | Cabin Entrance | - | - | 1 | |
| 75 | | AN4-30A | Bolt | - | Aircraft 1/4-28 | - | - | 2 | |
| 76 | | AN365-428 | Nut | - | Self Locking | - | - | 2 | |
| 77 | 8170 | 3L1 | Loop | - | Baggage Tie Down Strap | - | - | 8 | |
| 78 | | AN3-5A | Bolt | - | Aircraft 10-32 | - | - | 2 | |
| 79 | | AN960-10 | Washer | - | Plain | - | - | 2 | |
| 80 | | AN365-1032 | Nut | - | Self Locking | - | - | 2 | |
| 81 | 4452 | 145-53071-4 | Strap Assy | - | Baggage Tie Down (Includes Buckle) | - | - | 4 | |
| | 4453 | 145-53071-5 | Strap Assy | - | Baggage Tie Down | - | - | 1 | |
| 82 | 1416 | 143-31002-3 | Frame | - | Fuselage Station 65 Lower LH | - | - | 1 | |
| | 1417 | 143-31002-4 | Frame | - | Fuselage Station 65 Lower RH | - | - | 1 | |
| 83 | 1515 | 143-31002-7 | Frame | - | Fuselage Station 65 Center LH | - | - | 1 | |
| | 1516 | 143-31002-8 | Frame | - | Fuselage Station 65 Center RH | - | - | 1 | |
| 84 | 1517 | 143-31002-11 | Frame | - | Fuselage Station 65 Upper LH | - | - | 1 | |
| | 1518 | 143-31002-12 | Frame | - | Fuselage Station 65 Upper RH | - | - | 1 | |
| 85 | 1418 | 143-31002-35 | Angle | - | Step Lower Support Forward (LH Only) | - | - | 1 | |
| 86 | 1419 | 143-31002-36 | Angle | - | Step Lower Support Aft (LH Only) | - | - | 1 | |
| 87 | 1523 | 143-31002-47 | Frame | - | Fuselage Station 71.5 LH | - | - | 1 | |
| | 1524 | 143-31002-48 | Frame | - | Fuselage Station 71.5 RH | - | - | 1 | |
| 88 | 1422 | 143-31002-5 | Frame | - | Fuselage Station 77 Lower LH | - | - | 1 | |
| | 1423 | 143-31002-6 | Frame | - | Fuselage Station 77 Lower RH | - | - | 1 | |
| 89 | 1519 | 143-31002-9 | Frame | - | Fuselage Station 77 Center LH | - | - | 1 | |
| | 1520 | 143-31002-10 | Frame | - | Fuselage Station 77 Center RH | - | - | 1 | |
| 90 | 1521 | 143-31002-13 | Frame | - | Fuselage Station 77 Upper LH | - | - | 1 | |
| | 1522 | 143-31002-14 | Frame | - | Fuselage Station 77 Upper RH | - | - | 1 | |
| 91 | 1424 | 143-31002-43 | Frame | - | Fuselage Station 80.356 Lower LH | - | - | 1 | |
| | 1425 | 143-31002-44 | Frame | - | Fuselage Station 80.356 Lower RH | - | - | 1 | |
| 92 | 1426 | 143-31002 SA 5 | Frame Assy | - | Fuselage Station 93.438 Complete | - | - | 1 | |
| 93 | 1427 | 143-31002-15 | Frame | - | Fuselage Station 93.438 LH | - | - | 1 | |
| | 1428 | 143-31002-16 | Frame | - | Fuselage Station 93.438 RH | - | - | 1 | |
| 94 | 1429 | 143-31002-30 | Plate | - | Fuselage Station 93.438 Joining | - | - | 1 | |
| 95 | 1525 | 143-31001-63 | Frame | - | Fuselage Station 68.125 Upper | - | - | 1 | |
| 96 | 1526 | 143-31001-33 | Frame | - | Fuselage Station 72.75 Upper | - | - | 2 | Model B |
| 97 | 1554 | 143-31001-427 | Stiffener | - | Fuselage Station 93.438 to 106.25 | - | - | 2 | |
| 98 | 1556 | 143-31001-98 | Stiffener | - | Fuselage Station 93.438 to 106.25 | - | - | 1 | |
| 99 | 1527 | 143-31001-13 | Frame | - | Fuselage Station 106.25 LH | - | - | 1 | |
| | 1528 | 143-31001-14 | Frame | - | Fuselage Station 106.25 RH | - | - | 1 | |
| 100 | 1557 | 143-31001-415 | Stiffener | - | Fuselage Station 115 LH | - | - | 1 | Model B |
| | 1558 | 143-31001-416 | Stiffener | - | Fuselage Station 115 RH | - | - | 1 | Model B |
| 101 | 1529 | 143-31001-15 | Frame | - | Fuselage Station 123.437 LH | - | - | 1 | |
| | 1530 | 143-31001-16 | Frame | - | Fuselage Station 123.437 RH | - | - | 1 | |
| 102 | 1559 | 143-31001-417 | Stiffener | - | Fuselage Station 123.437 to 142.57 LH | - | - | 1 | Model B |
| | 1560 | 143-31001-418 | Stiffener | - | Fuselage Station 123.437 to 142.57 RH | - | - | 1 | Model B |
| 103 | 1531 | 143-31001-17 | Frame | - | Fuselage Station 142.57 LH | - | - | 1 | |
| | 1532 | 143-31001-18 | Frame | - | Fuselage Station 142.57 RH | - | - | 1 | |
| 104 | 1535 | 145-31109-1 | Intercostal | - | Rear Armrest LH | - | - | 1 | 2 - 1789 |
| | 1535-10 | 145-31109-3 | Intercostal | - | Rear Armrest LH | - | - | 1 | 1790 & Subs |
| | 1536 | 145-31109-2 | Intercostal | - | Rear Armrest RH | - | - | 1 | 2 - 1789 |
| | 1536-10 | 145-31109-4 | Intercostal | - | Rear Armrest RH | - | - | 1 | 1790 & Subs |
| 105 | 1561 | 143-31001-101 | Stiffener | - | Fuselage Station 142.57 to 160.25 LH | - | - | 1 | 1111 & Subs |
| | 1562 | 143-31001-102 | Stiffener | - | Fuselage Station 142.57 to 160.25 RH | - | - | 1 | 1111 & Subs |
| 106 | 1533 | 143-31001-19 | Frame | - | Fuselage Station 160.25 LH | - | - | 1 | |
| | 1534 | 143-31001-20 | Frame | - | Fuselage Station 160.25 RH | - | - | 1 | |
| 107 | 1430 | 143-31006 | Frame Assy | - | Station 179.75 (See Page 21 for Details) | - | - | 1 | Ref |
| 108 | 1483 | 143-31001-3 | Longeron | - | Fuselage Upper Forward LH | - | - | 1 | |
| | 1484 | 143-31001-4 | Longeron | - | Fuselage Upper Forward RH | - | - | 1 | |
| 109 | 1485 | 143-31001-5 | Longeron | - | Fuselage Upper Aft LH | - | - | 1 | |
| | 1486 | 143-31001-6 | Longeron | - | Fuselage Upper Aft RH | - | - | 1 | |
| 110 | 1563 | 143-31001-411 | Doubler | - | Longeron Station 79 to 101 Upper LH | - | - | 1 | Model B |
| | 1564 | 143-31001-412 | Doubler | - | Longeron Station 79 to 101 Upper RH | - | - | 1 | Model B |
| 111 | 1565 | 143-31001-429 | Doubler | - | Longeron Station 97 to 106.25 Upper Lower | - | - | 2 | Model B |
| 112 | 1487 | 143-31001-7 | Longeron | - | Fuselage Lower Forward LH | - | - | 1 | |
| | 1488 | 143-31001-8 | Longeron | - | Fuselage Lower Forward RH | - | - | 1 | |
| 113 | 1566 | 143-31002-66 | Doubler | - | Longeron Station 77 to 93.438 Lower | - | - | 2 | Model B |
| 114 | 1489 | 143-31001-9 | Longeron | - | Fuselage Lower Aft LH | - | - | 1 | |
| | 1490 | 143-31001-10 | Longeron | - | Fuselage Lower Aft RH | - | - | 1 | |