



FIGURE 20 - ELECTRIC DRIVEN FUEL PUMP

KEY	ITEM NO.	PART NUMBER	1	2	3	4	NOMENCLATURE	UNITS PER ASSY	USAGE
	9098	19372					Fuel Pump Assy - Electric Driven (Adel)	1	1111-1564
	9098-10	20113					Fuel Pump Assy - Electric Driven (Adel)	1	1565 & Subs
	9098-11	20113 SPEC.					Fuel Pump Assy (Without Manifold Block)	1	
1	9098-105	42300-6					Seal - "O" Ring Packing	1	
2	9098-110	8813					Brush Assy - Pump Motor	2	
3	9098-115	8814					Plug - Brush Holder	2	
4	9098-120	15799					Gasket - Power Package Plate	1	
5	9098-130	19197					Gasket - Heater Pump Housing	1	
6	9098-135	19365					Bolt - By Pass and Relief Valve	2	
7	9098-141	21553					Spring - Fuel Pump Seal	1	
8	9098-145	43131-32					Screw - Short Socket Cap	1	
	9098-150	43131-37					Screw - Long Socket Cap	2	
9	9098-155	43400-5					Washer - Lock Spring Type	3	
10	9098-160	16040					Pin - Pump Shaft	1	
	9098-125	19075					Seal - Heater Pump Cartridge	1	
11	9098-180	19077					Cartridge Assy - Heater Pump	1	
	9098-165	42300-7					Seal - "O" Ring Packing	4	
12	9098-185	19174					Washer - Heater Fuel Pump	3	
13	9098-190	42773-31					Screw - Heater Pump	3	
14	9098-170	8332					Pin - Motor Drive Shaft	1	
15	9098-175	20058					Coupling - Heater Fuel Pump	1	1565 & Subs
16		AN3102-108-2P					Receptacle	1	
17		8/32X1 13/16					Screw - Socket Head Cap	2	
18		AC500-4-5					Screw	4	