



FIGURE 41 - ELECTRICAL EQUIPMENT (CONT)

KEY	ITEM NO.	PART NUMBER	1	2	3	4	NOMENCLATURE	UNITS PER ASSY	USAGE
	9322	3AG-2AMP					Fuse - (Turn & Bank Indicator) - - - - -	2	
39	4320-10	145-54023					Panel Assy - Circuit Breaker - - - - -	1	251 & Subs
40	9328	CM5					Circuit Breaker - - - - -	4	251 - 1564
	9328	CM5					Circuit Breaker - - - - -	3	1565 & Subs
41	9328-100	CM10					Circuit Breaker - - - - -	1	1565 & Subs
42	9329	CM15					Circuit Breaker - - - - -	2	251 - 2025
	9329	CM15					Circuit Breaker - - - - -	1	2016 & Subs
43	9330	CM20					Circuit Breaker - - - - -	1	251 & Subs
44	9331	CA20					Circuit Breaker - - - - -	1	251 & Subs
		AN530-8R10					Screw - Sheet Metal Round Head - - - - -	2	
	9004	A1778-8Z-1					Nut - Speed - - - - -	2	
45	3129	145-54025					Spring - Fuse and Circuit Breaker Panel Retaining - - - - -	1	
46	9333	L14001					Lighter - Cigarette Complete - - - - -	1	
	9333-1	LHA29236					Knob & Element - Cigarette Lighter - - - - -	1	
	9334	LFA2850A					Fuse - Cigarette Lighter Thermal Safety - - - - -	1	
	4322	145-54036					Spring - Cigarette Lighter Retainer - - - - -	1	
47	4323	145-54007					Light Assy - Landing Complete - - - - -	2	
48	4324	145-54007-3					Channel - Landing Light Support - - - - -	1	
49	4326	145-54007-10					Shell Assy - Landing Light - - - - -	1	
50		AN515-8R9					Screw - Round Head Machine (Coarse Thread) - - - - -	2	
51		AN960-8					Washer - Plain - - - - -	2	
52	9057	4509					Lamp - 12 Volt 100 Watt Landing Light - - - - -	1	
53	4327	144-54246					Gasket - Landing Light Lamp - - - - -	1	
54	4328	144-54245					Retainer - Landing Light Lamp - - - - -	1	
55		AN520-10R5					Screw - Round Head Machine (Fine Thread) - - - - -	3	
56		AN365-1032					Nut - Self Locking - - - - -	3	
57	4325	145-54008					U-Bolt - Landing Light Attaching - - - - -	4	
		AN960-10					Washer - Plain - - - - -	2	
		AN365-1032					Nut - Self Locking - - - - -	2	
58		71-111242					Relay - Battery Disconnect - - - - -	1	
59	9285	145-54031					Cover - Battery Disconnect Relay - - - - -	1	
	4315	781-10-7					Screw - Button Head - - - - -	2	
	8405	AN960-10					Washer - Plain - - - - -	2	
		AN365-1032					Nut - Self Locking - - - - -	2	
60	9286	6-TAS-9B					Battery - 12 Volt 34 Amp (Exide) - - - - -	1	
61	4331	145-54016-41					Cover Assy - Battery Box - - - - -	1	
62	4332	145-54016-51					Box - Battery Lower Half (Includes Cables) - - - - -	1	
	9287	4300					Boat - Terminal (Battery, Starter & Starter Switch) - - - - -	4	
	9288	6846					Boat - Terminal (Generator) - - - - -	2	
63	4333	143-54801-2					Line - Battery Vent - - - - -	1	
64	9536	A3122-8-59					Clamp - Hose - - - - -	1	
		AN931-7-11					Grommet - Elastic - - - - -	2	
65	4334	145-54001 SA8E					Light Assy - Flap Midway Position Complete - - - - -	1	1790 & Subs
		AN515-6R8					Screw - Round Head Machine (Coarse Thread) - - - - -	2	
	9019	6939-632-062					Nut - Speed - - - - -	2	
	9053-10	#53					Lamp - 12 Volt Min Bayonet Base 1 CP Clear - - - - -	1	
67	9277	8215-K4 (AN3022-11)					Switch - (Main Gear Down Position Indicating) - - - - -	2	
	4301	145-54039					Spring - Landing Gear Warning Horn Switch - - - - -	1	
		AN515-6R6					Screw - Round Head Machine (Coarse Thread) - - - - -	1	
		AN515-6R8					Screw - Round Head Machine (Coarse Thread) - - - - -	1	
		AN960-6					Washer - Plain - - - - -	2	
	4321	145-54010-3					Plate - Main Gear Down Switch Support - - - - -	1	
	8363	484-5-8					Spacer - Rivet - - - - -	2	
68	9277	8215-K4 (AN3022-11)					Switch - (Main Gear Up Position Indicating) - - - - -	2	2 - 1789
	9278	8715 (AN3023-10)					Switch - (Main Gear Up Position Indicating) - - - - -	2	1790 & Subs
	4301	145-54039					Spring - Landing Gear Warning Horn Switch - - - - -	1	
		AN515-6R6					Screw - Round Head Machine (Coarse Thread) - - - - -	1	
		AN515-6R8					Screw - Round Head Machine (Coarse Thread) - - - - -	1	
		AN960-6					Washer - Plain - - - - -	2	
	4335	145-54048-1					Bracket - Main Gear Up Switch Support LH - - - - -	1	
	4336	145-54048-2					Bracket - Main Gear Up Switch Support RH - - - - -	1	