



PRICE LIST

ITEM NO.	PART NUMBER	PAGE	NOMENCLATURE	LIST PRICE
4110	145-52010-5	77	Cable Assy-Aileron Control	7.55
4111	145-52202-29	77	Bracket-Column Mounting	1.15
4200	145-52019-10	79	Rod Assy-Wing Flap Actuating	5.75
4201-10	145-52019-2	79	Stud-Flap Actuating Rod	.90
4202	145-52022 SA 1	79	Support Assy-Flap Cylinder	13.35
4203	145-52022-3	79	Strap-Wing Flap Cyl Support	.70
4204	145-52022-9	79	Bracket-Wing Cyl Support LH	2.70
4205	145-52022-10	79	Bracket-Wing Cyl Support RH	2.70
4206	145-52022-5	79	Angle-Wing Cyl Support LH	1.75
4207	145-52022-6	79	Angle-Wing Cyl Support RH	1.75
4208	145-52026	79	Tube Assy-Flap Torque	24.75
4209	145-52027	79	Support-Torque Tube Center	1.15
4210	143-18051-1	79	Bushing-Flap Hinge Spacer	.20
4211	143-18051-2	79	Bushing-Flap Hinge Spacer	.20
4213	143-18051-4	7	Bushing-Flap Hinge Spacer	.20
4214	145-52024-2	79	Support-Torque Tube Outbd RH	4.40
4215	145-52024-1	79	Support-Torque Tube Outbd LH	4.40
4216	145-52021	79	Bellcrank Assy-Flap Strut	7.05
4217	145-52028	79	Rod-Wing Flap Tor Tube Push	2.35
4300	143-54038	81	Bracket-Warning Horn Switch	1.25
4300-10	145-54058-2	81	Bracket-Warning Horn Switch	1.25
4300-20	146-54017-5	81	Bracket-Warning Horn Switch	1.60
4301	145-54039	81	Spring-Warning Horn Switch	.65
4302	145-54050	81	Bracket-Down Position Switch	1.50
4302-10	145-54063	81	Bracket-Down Position Switch	1.50
4303	145-54051	81	Bracket-Up Position Switch	1.50
4303-10	145-54077	81	Bracket-Up Position Switch	1.50
4304	145-54011	81	Bracket-Nose Gear Pos Switch	1.50
4305	145-54052	81	Arm Assy-Nose Gear Position	6.30
4306	145-54013	81	Bellcrank-Foot Starter Cont	6.60
4307	145-54054	81	Bracket-Foot Starter Cont	1.75
4308	145-54014	81	Pedal-Foot Starter Control	2.80
4309	145-54021	81	Cable Assy-Starter Control	7.00
4310	145-54056	81	Link-Starter Lever Spring	1.15
4311	145-54057	81	Bracket-Lever Return Spring	.50
4312	145-54055	81	Spring-Lever Return Spring	.45
4313	145-54045	81	Bolt-Starter Switch	2.55
4314	145-54042	81	Horn Assy-Gear Warning	8.80
4315	145-54031	81	Lens-Cabin Light	1.50
4316	145-54032	81	Retainer-Cabin Light Lens	.80
4318	145-54005	73	Lever Assy-Switch Operating	2.40
4319	145-51061-5	73	Knob-Instr Panel Control	1.65
4320	145-54024	81	Panel Assy-Fuse	10.40
4320-10	145-54023	81A	Panel Assy-Circuit Breaker	26.25
4321	145-54010-3	81A	Plate-Gear Dn Switch Sup	.25
4322	145-54036	81A	Spring-Cigarette Lighter	.65
4323	145-54007	81A	Light Assy-Landing Complete	14.30 e
4324	145-54007-3	81A	Channel-Landing Light Sup	3.30 e
4325	145-54008	81A	U-Bolt-Landing Light Attach	.50 e
4326	145-54007-10	81A	Shell Assy-Landing Light	3.10 e
4327	144-54246	81A	Gasket-Landing Light Lamp	.60 e