

LIST OF ILLUSTRATIONS

SECTION I

GENERAL

Figure	Title	Page	Figure	Title	Page
1-1.	Major Assemblies - Exploded View	2	1-3.	Leveling Airplane	5
1-2.	Airplane Alignment Dimensions	4	1-4.	Jacking Airplane	5

SECTION II

WING GROUP

2-1.	Wing Structure	8	2-6.	Wing Stringer Repairs	18
2-2.	Wing Skin Arrangement	9	2-7.	Aileron Jig Dimensions	20
2-3.	Wing Skin Insertion	10	2-8.	Wing Jig Dimensions	21
2-4.	Front Beam and Center Beam Splice	12	2-9.	Flap Jig Dimensions	22
2-5.	Front Beam and Center Beam Lightening Hole Repair	15			

SECTION III

TAIL GROUP

3-1.	Tail Structure	24	3-4.	Horizontal Tail Jig Dimensions	33
3-2.	Tail Skin Arrangement	25	3-5.	Vertical Tail Jig Dimensions	34
3-3.	Horizontal and Vertical Stabilizer Beam Repair	27			

SECTION IV

BODY GROUP

4-1.	Fuselage Structure	36	4-3.	Fuselage Frame Repair	38
4-2.	Fuselage Skin Arrangement	36	4-4.	Fuselage Longerons Repair - Upper and Lower	41

SECTION V

ALIGNING GEAR

5-1.	Nose and Main Landing Gear	44	5-3.	Main Landing Gear Trunnion Repair	46
5-2.	Main Landing Gear Axle Housing Repair . .	45			

SECTION VI

ENGINE SECTION

6-1.	Engine Mount and Cowling Structure	48	6-3.	Engine Mount Lower Longerons Repair . . .	52
6-2.	Engine Mount Upper Longerons Repair	50			

SECTION VIII

STANDARD AND EQUIVALENT

STRUCTURAL SECTIONS

8-1.	Extrusion Equivalents	56	8-2.	Rolled Section Equivalents	61
------	---------------------------------	----	------	--------------------------------------	----

APPENDIX II

TYPICAL REPAIR ILLUSTRATIONS

B-1.	Flush Skin Patch	71	B-4.	Nonstructural Negligible Damage Patch . .	74
B-2.	Leading Edge Flush Skin Patch	72	B-5.	Typical Rib Repairs	75
B-3.	External Skin Patch	73	B-6.	Lightening Hole Flange Repair	77