

Paragraph	Page	Paragraph	Page
3-79. Leading Edge Repair, Clear Of Internal Structure	30	3-100. Description	31
3-80. Leading Edge Repair, Over Internal Structure	30	3-101. Negligible Damage	31
3-81. Damage Repairable By Insertion	30	3-102. Damage Repairable By Patching	31
3-82. Damage Necessitating Replacement	30	3-103. Damage Necessitating Replacement	31
3-83. Vertical Stabilizer Beam	30	3-104. Rudder Main Beam	31
3-84. Description	30	3-105. Description	31
3-85. Negligible Damage	30	3-106. Negligible Damage	31
3-86. Damage Repairable By Patching	30	3-107. Damage Repairable By Patching	31
3-87. Damage Repairable By Insertion	30	3-108. Damaged Flange And Adjacent Web	31
3-88. Damage Repairable By Replacement	30	3-109. Rudder Beam Splice	31
3-89. Beam Cap Angles	30	3-110. Damage Repairable By Insertion	31
3-90. Beam - Root To Station 13.3	30	3-111. Rudder Auxiliary Beam	31
3-91. Beam - Station 13.3 To Tip	30	3-112. Description	31
3-92. Vertical Stabilizer Ribs	30	3-113. Negligible Damage	31
3-93. Description	30	3-114. Damage Repairable By Patching	31
3-94. Negligible Damage	30	3-115. Rudder Ribs	31
3-95. Damage Repairable By Patching	30	3-116. Description	31
3-96. Damage Repairable By Insertion	30	3-117. Negligible Damage	31
3-97. RUDDER	31	3-118. Damage Repairable By Patching	31
3-98. Description	31	3-119. Damage Necessitating Replacement	32
3-99. Rudder Skin	31	3-120. Rudder Trim Tab	32
		3-121. Description	32
		3-122. Negligible Damage	32
		3-123. Damage Necessitating Replacement	32

SECTION IV

BODY GROUP

4-1. GENERAL	35	4-32. Description	39
4-2. Description	35	4-33. Negligible Damage	39
4-3. Alignment	35	4-34. Damage Repairable By Patching	39
4-4. Access For Repair	35	4-35. Damage Repairable By Insertion	39
4-5. SKIN	35	4-36. Damage Necessitating Replacement	39
4-6. Description	35	4-37. Frame At Station 179.75	39
4-7. Negligible Damage	35	4-38. Description	39
4-8. Damage Repairable By Patching	35	4-39. Negligible Damage	39
4-9. General	35	4-40. Damage Repairable By Patching	39
4-10. Flush Skin Patch Clear of Internal Structure	35	4-41. Frames at Stations 198, 224, 249.5, 273.118 and 294.1	39
4-11. Flush Skin Patch Over Internal Structure	35	4-42. Description	39
4-12. External Skin Patches	35	4-43. Negligible Damage	39
4-13. BULKHEADS AND FRAMES	35	4-44. Damage Repairable By Patching	39
4-14. General	35	4-45. Bulkhead, Station 311.07	39
4-15. Description	35	4-46. Description	39
4-16. Firewall, Station 54	35	4-47. Negligible Damage	39
4-17. Description	35	4-48. Damage Necessitating Replacement	39
4-18. Negligible Damage	35	4-49. WING AFT ATTACHMENT BEAM	39
4-19. Web Damage Repairable By Patching	35	4-50. Description	39
4-20. Damaged Bulkhead Flanges Repairable By Patching	37	4-51. Negligible Damage	39
4-21. Damaged Splice Angle Between Upper And Lower Web Repairable By Patching	37	4-52. Damage Repairable By Patching	39
4-22. Damaged Vertical Channel Supporting Nose Gear Housing Repairable By Patching	37	4-53. CROSS BAR AT STATION 147.125	39
4-23. Frames At Station 65.0 And 77.0	37	4-54. Description	39
4-24. Description	37	4-55. Negligible Damage	40
4-25. Negligible Damage	37	4-56. Damage Necessitating Replacement	40
4-26. Damage Repairable By Insertion	37	4-57. CABIN ENCLOSURE FLOOR	40
4-27. Forward Wing Attachment Frame, Station 93.438	37	4-58. Description	40
4-28. Description	37	4-59. Negligible Damage	40
4-29. Negligible Damage	37	4-60. Damage Repairable By Patching	40
4-30. Damage Repairable By Patching	37	4-61. NOSE GEAR BEAMS	40
4-31. Frames At Station 106.25, 123.437, 142.57, and 160.25	39	4-62. Description	40
		4-63. Negligible Damage	40
		4-64. Damage Repairable By Patching	40
		4-65. BAGGAGE COMPARTMENT FLOOR	40
		4-66. Description	40
		4-67. Access For Repair	40