

Part No.	Part Name	Heat Treat P.S.I.	Com'l Desig'n	Material Specification	Material
145-34203	Ring - Aux. Ldg. Gr. Bearing Retainer	90,000	8735	AMS 6283	C.N.M. Steel
145-34206	Ring - Aux. Ldg. Gr. Inner Cyl. External Stop	90,000	8735	AMS 6283	C.N.M. Steel
145-34314-3	Crank Assem. - Drag Link Torque Tube	90,000	4130	AN-WW-T-850	C.M. Steel
145-37175-5	Bellcrank Assem. - Aux. Ldg. Gr. Steering Mech.	160,000	4130	AN-QQ-S-684	C.M. Steel
145-44014	Bracket Assem. - Hartzell Prop. Control Cycl. Support	90,000	4130	AN-QQ-S-685	C.M. Steel
145-48068-2	Torque Tube - Fuel Shutoff Valve Tube	95,000	4130	AN-T-69	C.M. Steel
145-48068-3	Torque Tube - Fuel Shutoff Valve Tube	95,000	4130	AN-T-69	C.M. Steel
145-48068-4	Torque Tube - Fuel Shutoff Valve Arm	95,000	4130	AN-QQ-S-684	C.M. Steel
145-48075	Adapter - Fuel Shutoff Valve Torque Tube	95,000	4130	AN-QQ-S-684	C.M. Steel
145-48244	Pin - Selector Valve Detent.	180,000	4130	AN-QQ-S-684	C.M. Steel
145-52021-3	Bell Crank Assem. - Wing Flap Strut	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52021-4	Bell Crank Assem. - Wing Flap Strut	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52026-3	Tube Assem. - Wing Flap Operating Torque - Plate	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52026-4	Tube Assem. - Wing Flap Operating Torque - Tube	90,000	4130	AN-WW-T-850	C.M. Steel
145-52026-5	Tube Assem. - Wing Flap Operating Torque - Arm	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52026-6	Tube Assem. - Wing Flap Operating Torque - Arm	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52026-7	Tube Assem. - Wing Flap Operating Torque - Arm	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52027	Support - Wing Flap Torque Tube Center	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52202-3	Column Assem. & Install. - Elev. & Aileron Cont'l - Arm	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52202-5	Column Assem. & Install. - Elev. & Aileron Cont'l - Arm	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52202-15	Column Assem. & Install. - Elev. & Aileron Cont'l - Tube	90,000	4130	AN-WW-T-850	C.M. Steel
145-52202-17	Column Assem. & Install. - Elev. & Aileron Cont'l - Tube	90,000	4130	AN-WW-T-850	C.M. Steel
145-52202-19	Column Assem. & Install. - Elev. & Aileron Cont'l - Tube	90,000	4130	AN-WW-T-850	C.M. Steel
145-52202-47	Column Assem. & Install. - Elev. & Aileron Cont'l - Spacer	90,000	4130	AN-WW-T-850	C.M. Steel
145-52218-3	Link - Control Cable	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52218-5	Link - Control Cable	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52401-3	Pedal Assem. & Install. - Rudder Tube	90,000	4130	AN-WW-T-850	C.M. Steel
145-52401-5	Pedal Assem. & Install. - Rudder Tube	90,000	4130	AN-WW-T-850	C.M. Steel
145-52401-7	Pedal Assem. & Install. - Rudder Tube	90,000	4130	AN-WW-T-850	C.M. Steel
145-52501-24	Contr. Assem. & Install. - Elev. Trim Tab Operating, Tube	90,000	4130	AN-WW-T-850	C.M. Steel
145-52505-7	Contr. Assem. & Install. - Fus. Sta. 274 - Elev. Trim Tab, Strap	90,000	4130	AN-QQ-S-685	C.M. Steel
145-52505-14	Cont. Assem. & Install. - Fus. Sta. 274 - Elev. Trim Tab, Spacer	90,000	4130	AN-QQ-S-684	C.M. Steel
145-53005-5	Lock Assem. - Front Seat, Handle	90,000	4130	AN-QQ-S-684	C.M. Steel
145-53005-6	Lock Assem. - Front Seat, Clamp	90,000	4130	AN-QQ-S-685	C.M. Steel
145-53054-1	Fitting - Safety Belt Attachment	90,000	4130	AN-QQ-S-685	C.M. Steel
145-53054-2	Fitting - Safety Belt Attachment	90,000	4130	AN-QQ-S-685	C.M. Steel
145-58237	Spacer - Hyd. Hand Brake Travel Adjusting	90,000	4130	AN-WW-T-830	C.M. Steel